



INSTALLATION INSTRUCTIONS

Thank you for purchasing a 4x4 Armour product. Installation on your vehicle is simple but will take a little getting used to the first few times you place the magnetic sheeting on your vehicle. Below, we have described the best way to do this.

1. **BEFORE USE:** Vehicle: We recommend you wash your vehicle prior to any use of the 4x4 Armour. This allows there to be no debris in between your vehicle and the magnetic side on the 4x4 Armour. 4x4 Armour **SHOULD NOT** be put on a wet surface. Ensure the vehicle is thoroughly dry before use. Water trapped between your 4x4 Armour and your paint, could affect your paintwork.
2. **BEFORE USE:** 4x4 Armour: We recommend that you wipe down the Magnetic side of each panel with a clean, dry cloth prior to installation on your vehicle. This allows a clear and clean bond to the surface of your vehicle. The magnetic panels and your vehicle panels should be free from dust, dirt and moisture before use.
3. Your 4x4 Armour comes rolled up, on a core with protective sheeting in between each sheet.
4. Roll out your 4x4 Armour on a wide, flat surface. The floor or a wide table is recommended. We also recommend placing a sheet or blanket, flat on the surface to roll out on to, the first time you use the product.
5. Each sheet represents a panel, or part of a panel if there is more than one piece to a panel. The pieces are numbered and named on a small sticker on the magnetic side of the panel. There may be more than one piece to cover one panel due to the curvature of the vehicle panel.
6. Abbreviations:
 - a) PFQ: **P**assenger side **F**ront **Q**uarter panel
 - b) PFD: **P**assenger side **F**ront **D**oor
 - c) PRD: **P**assenger side **R**ear **D**oor
 - d) PRQ **P**assenger side **R**ear **Q**uarter panel
 - e) DFQ: **D**river side **F**ront **Q**uarter panel
 - f) DFD: **D**river side **F**ront **D**oor
 - g) DRD: **D**river side **R**ear **D**oor
 - h) DRQ: **D**river side **R**ear **Q**uarter panel
 - i) LB: Left Bonnet (if applicable)
 - j) RB: Right Bonnet (if applicable)

NB: There can be more than one piece to a panel. If this is the case with your vehicle, it will be marked Top / Bottom / Middle and/or Front / Back – example: PRQ front – this would indicate that there is a Passenger Rear Quarter front and back piece.

7. Start by finding the top of each panel. Usually the straightest edge represents the top of the door etc.
8. Only put one piece on at a time. Start by picking up a piece at the top left and right corners, with the magnetic side away from you, and letting the piece hang down naturally.
9. Hold the magnetic side of the panel approx. 2-5 cm from the panel and try and get the top edge to run parallel with the panel you are putting it on whilst trying to keep the rest of the 4x4 Armour off the panel.
10. Let the magnet do the work by allowing the top edge to attract itself to your vehicle.

11. Starting at the top and working your way down, gently assist and let the magnet attract to the rest of the panel, all the way to the bottom.
12. Remember, the 4x4 Armour isn't held on by anything other than Magnet so don't worry if it isn't perfectly straight or has bubbles in it. Simply peel it back from a corner up to where the bubbles are or to get it straighter. It takes a little getting used to at the beginning.
13. PLEASE NOTE: NEVER try and slide the Magnetic Sheet into place. The entire surface is magnetic and it will want to bond to the vehicle wherever it touches. Trying to slide the magnet may result in scratches to your vehicles paint work. If you don't put it on perfectly to start, you simply peel it back off and start again.
14. Working your way around the vehicle, one piece at a time, follow these instructions for each piece.
15. If there are more than one piece for a singular panel, they will be numbered and/or marked so you know where the panel goes on your vehicle.

The panels come in range of sizes and shapes to fit your specific vehicle.

DO's and DON'T's:

1. **DO NOT** FOLD or BEND your panel for storage or any other reason. The material, although strong and robust, if folded or bent backwards, may result in a permanent crease in your panel. It will not split or tear your panel due to the vinyl holding it together but may result in a crease which may make installation difficult and be unsightly.
2. **DO NOT** leave your 4x4 Armour on your vehicle for extended periods of time. By this, we mean, the 4x4 Armour is not designed to be permanently on your vehicle. It is however, specifically designed for use off-road, on tracks and for scratch protection against brushes, shrubs and small rocks that may flick up and hit your vehicle whilst in the bush.
3. **DO** hose down and wash your 4x4 Armour after each use. We recommend you wash your 4x4 Armour on your vehicle as it much easier to clean it whilst still attached to your vehicle.
4. **DO** store your 4x4 Armour either on a flat surface in your garage or similar, out of direct sunlight for extended periods. Or you can roll your 4x4 Armour back onto the core that came with your panels and tape the edges to stop it unrolling. Remember, your 4x4 Armour doesn't like to be folded or bent so make sure you roll it nice and tight around the core before taping it. We have found, the best and most secure way to do this is to lay all the panels on top of each other on a clean surface. Start with the longest pieces of your 4x4 Armour (usually the doors or rear quarter if you have a Ute) and work your way around the vehicle placing each piece, from largest to smallest on top of each other. Using the core, tape the start of the longest piece to the roll. Roll towards the centre until all the 4x4 Armour is on the roll.

We have created an instructional video for you to help you with the whole process. It can be found at www.4x4armour.com.au/FAQ

Once again, thank you for your purchase. We are sure that you get many years use out of our product and have many a great trip with family and friends, knowing your vehicle is protected by the ultimate in Removable, Reusable Panel Protection.

Enjoy and Safe Travels!

4x4 Armour

Burleigh Heads, Queensland 4220

Web: www.4x4armour.com.au Email: sales@4x4armour.com.au Phone: 0421 20 34 34